

EARTH SPIKE - COPPER - 1.2M (NUT/WASHER)



The copper cladded earth spike or stake is used to earth the electric fence system. A minimum of 3 earth spikes must be knock into the ground near the electric fence at a minimum of 1.5 m apart. Connect these earth spikes to the energizer or the fence using the high tension insulated cable (HT). In areas where earthing conditions are bad you may be required to add a few more earth spikes/stakes along the fence line and connect these back to the energiser.

Features: • Copper clad nuts and washers • Available in both 1.0m and 1.2m lengths • The double nut and washer allow for a good electrical connection with the HT cables

Specifications:

Lengths 10mm x 1.0m
10mm x 1.2m
Finish Copper Cladded

Stock Code	Description
EA-EAN/L	Earth Spike - Copper - 1.2m (nut/washer)