


EARTH SPIKE - COPPER - 1.2M (NUT/WASHER)



The copper clad earth spike or stake is used to earth the electric fence system. A minimum of 3 earth spikes must be knock into the ground near the electric fence at a minimum of 1.2m apart. Connect these earth spikes to the energizer or the fence using the high tension insulated cable (HT). In areas where earthing conditions are bad you may be required to add a few more earth spikes/stakes along the fence line and connect these back to the energiser.

Features: • Copper clad nuts and washers • Available in both 1.0m and 1.2m lengths • The double nut and washer allow for a good electrical connection with the HT cables

Specifications:

- Lengths

10mm x 1.0m

10mm x 1.2m
- Finish

Copper Cladded

Stock Code	Description
EA-EAN/L	Earth Spike - Copper - 1.2m (nut/washer)